





Endcap Mounting Instructions



Don't reuse
old bolts!

3x 

Use included
new bolts!

Threadlocker

For example
Loctite 266

3x 

**6Nm
4lbf ft**

300 km
186 mi

3x 